


WIRING DIAGRAM

NOTE: This diagram is for reference only. It is not accurate for all machines covered by this manual. The specific diagram for a particular code is pasted inside the machine on one of the enclosure panels. If the diagram is illegible, write to the Service Department for a replacement. Give the machine code number.



PRINT TO SIZE 6.00 x 9.00

M-14348
8-30-85G